

Software Functions

- ALS mode for internal testing and result transmission to PC.
- Heterogeneous mode for partial testing on the device and computation on the PC.
- Acquisition mode for direct image data transfer to the PC.

Dimensions

